

# 纸张薄

WWW.KRASPULT.RU

WWW.KRASPULT.RU

WWW.KRASPULT.RU

## HUAYU DVB-T2+3

### INSTRUCTION FOR UNIVERSAL REMOTE CONTROL

Thank you for using the remote controller. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setting it. However, if it could not work well, it should be set with the following methods before remote controlling your DVB. The remote controller would not lose its memory when the power is down so that you could replace the battery without resetting it.

POWER Indicator lamp lights



For example: setting DC711HD  
At the same time  
Press "POWER" and "MUTE" of your remote until the light is on, release them, then enter "302"

**Settings of Remote controller:**  
The remote controller has the following methods of settings, please choose any of them.

#### Inputting code:

1. Turn on STB manually, make it in a normal play state, point the remote controller at the STB, and then find the corresponding 3-digit code of the corresponding brand from the code table.
2. Press "POWER" and "MUTE" key of your remote control model, until the light is on, then release two button, enter the corresponding code.
3. Test whether other function buttons (such as "Volume buttons") could work well. If not, repeat steps 2 and 3 until you find the suitable set of code.

#### Automatically searching code:

1. Turn on STB manually, make it in a normal play state, point the remote controller at the STB.
2. Press "POWER" button, and hold about 6 seconds, the remote control will turn to automatically search mode. When volume appear on your STB, release the button on time, set to be finished.
3. Test whether other function buttons (such as "Volume buttons") could work well. If not, repeat steps 2 until you find the suitable set of code.

#### Technical parameters:

Remote Controlling Distance: About 10 meters (varies by different types).  
Battery Type: two pieces of AAA Batteries.

русская

### Инструкция по эксплуатации универсального пульта дистанционного управления стандарта DVB-T2+3

Благодарим за использование данного пульта дистанционного управления. При первом использовании пульта, необходимо вставить батарейки питания и попробовать пульт в работе. В случае нормальной работы всех функций, при первом запуске дальнейшая настройка пульта не требуется. В противном случае, до начала использования необходимо произвести настройку одним из способов, предложенных ниже. Настройки пульта сохраняются в памяти, поэтому после замены батареек питания не требуется производить настройку пульта заново.

POWER Indicator lamp lights



For example: setting DC711HD  
At the same time  
Press "POWER" and "MUTE" of your remote until the light is on, release them, then enter "302"

### Настройка пульта дистанционного управления:


Для настройки пульта следует воспользоваться одним из способов, указанных ниже.

#### Автоматический поиск кода:

1. Включить телевизор вручную, настроить его на нормальный режим работы, направить пульт дистанционного управления на ресивер.
2. Нажать кнопку POWER (ВКЛЮЧИТЬ) и удерживать ее в течение 6 секунд. Всеволоется режим автоматического поиска кода. Данадётся появление индикатора громкости на экране телевизора, затем отпустить кнопку, чтобы завершить настройку.
3. Убедиться, что все остальные функции (например, кнопки изменения уровня громкости звука (Volume)) работают должным образом. При неправильной работе каких либо кнопок повторить инструкцию пунктов 1 и 3 до тех пор, пока не будет найдена подходящая комбинация.

#### Технические характеристики:

Дальность действия пульта дистанционного управления: около 10 метров (в зависимости от модели).  
Тип батарейки питания: 2 батарейки типа AAA



WWW.KRASPULT.RU

WWW.KRASPULT.RU

WWW.KRASPULT.RU

WWW.KRASPULT.RU

